Metalica

DESIGNERS' TOP CHOICE

Modern Design

Clip-On Ultra Slim Metallic Front Plate

Modern Design

Clip-On Ultra Slim Metallic Front Plate



Modern Design List

PRODUCT NUMBER EXPLANATION:

W□□□□

- SHROUD COLOUR
- PLATING COLOUR CODE
- PRODUCT CODE
- MODERN DESIGN RANGE

CATEGORY OF THE PLATING COLOUR:

COLOUR	PLATING COLOUR CODE
BLACK NICKEL	BN
POLISHED CHROME	PC
BRUSHED STEEL	BS
STAIN NICKEL	SN
POLISHED BRASS	PB
SATIN BRASS	SB
PURE GOLD	PG
PURE SILVER	PS

SHROUD COLOUR

COLOUR	SHROUD COLOUR CODE
WHITE	W
GREY	G
BLACK	B

*Remarks:'B'(BLACK) is only used for the plating colour of 'BN'(BLACK NICKEL) products.

EXAMPLE:

PRODUCT NO	PRODUCT CODE	PLATING COLOUR CODE	SHROUD COLOUR CODE
W01PCW	W01	PC	W
W01SBG	W01	SB	G
W01BNB	W01	BN	B

DESCRIPTION	BLACK NICKEL	POLISHED CHROME	BRUSHED STEEL	SATIN NICKEL	POLISHED BRASS	SATIN BRASS	PURE GOLD	PURE SILVER
10AX SWITCHES BS EN 60669 IEC 60669 SS 227 MS616								
10AX 1 GANG 1 WAY SWITCH	W01BNB	W01PCG or W	W01BSG or W	W01SNG or W	W01PBG or W	W01SBG or W	W01PGG or W	W01PSG or W
10AX 1 GANG 2 WAY SWITCH	W02BNB	W02PCG or W	W02BSG or W	W02SNG or W	W02PBG or W	W02SBG or W	W02PGG or W	W02PSG or W
10A 1 GANG 1 WAY BELL SWITCH	W07BNB	W07PCG or W	W07BSG or W	W07SNG or W	W07PBG or W	W07SBG or W	W07PGG or W	W07PSG or W
10A 1GANG 1 WAY PRESS SWITCH	W08BNB	W08PCG or W	W08BSG or W	W08SNG or W	W08PBG or W	W08SBG or W	W08PGG or W	W08PSG or W
10AX INTERMEDIATE SWITCH	W10BNB	W10PCG or W	W10BSG or W	W10SNG or W	W10PBG or W	W10SBG or W	W10PGG or W	W10PSG or W
CHROME 3 POLE FAN ISOLATOR SWITCH	W09BNB	W09PCG or W	W09BSG or W	W09SNG or W	W09PBG or W	W09SBG or W	W09PGG or W	W09PSG or W
10AX 2 GANG 1 WAY SWITCH	W03BNB	W03PCG or W	W03BSG or W	W03SNG or W	W03PBG or W	W03SBG or W	W03PGG or W	W03PSG or W
10AX 2 GANG 2 WAY SWITCH	W04BNB	W04PCG or W	W04BSG or W	W04SNG or W	W04PBG or W	W04SBG or W	W04PGG or W	W04PSG or W
10AX 3 GANG 1 WAY SWITCH	W05BNB	W05PCG or W	W05BSG or W	W05SNG or W	W05PBG or W	W05SBG or W	W05PGG or W	W05PSG or W
10AX 3 GANG 2 WAY SWITCH	W06BNB	W06PCG or W	W06BSG or W	W06SNG or W	W06PBG or W	W06SBG or W	W06PGG or W	W06PSG or W
10AX 4 GANG 1 WAY SWITCH	W41BNB	W41PCG or W	W41BSG or W	W41SNG or W	W41PBG or W	W41SBG or W	W41PGG or W	W41PSG or W
10AX 4 GANG 2 WAY SWITCH	W42BNB	W42PCG or W	W42BSG or W	W42SNG or W	W42PBG or W	W42SBG or W	W42PGG or W	W42PSG or W
10AX 6 GANG 1 WAY SWITCH	W43BNB	W43PCG or W	W43BSG or W	W43SNG or W	W43PBG or W	W43SBG or W	W43PGG or W	W43PSG or W
10AX 6 GANG 2 WAY SWITCH	W44BNB	W44PCG or W	W44BSG or W	W44SNG or W	W44PBG or W	W44SBG or W	W44PGG or W	W44PSG or W
10AX 1 GANG 1 WAY LARGE DOLLY SWITCH	W80BNB	W80PCG or W	W80BSG or W	W80SNG or W	W80PBG or W	W80SBG or W	W80PGG or W	W80PSG or W
10AX 1 GANG 1 WAY LARGE DOLLY SWITCH WITH NEON	W80LBNB	W80LPCG or W	W80LBSG or W	W80LSNG or W	W80LPBG or W	W80LSBG or W	W80LPGG or W	W80LPSG or W
10AX 1 GANG 2 WAY LARGE DOLLY SWITCH	W81BNB	W81PCG or W	W81BSG or W	W81SNG or W	W81PBG or W	W81SBG or W	W81PGG or W	W81PSG or W
10AX 1 GANG 2 WAY LARGE DOLLY SWITCH WITH NEON	W81LBNB	W81LPCG or W	W81LBSG or W	W81LSNG or W	W81LPBG or W	W81LSBG or W	W81LPGG or W	W81LPSG or W
10A 1 GANG 1 WAY LARGE DOLLY BELL SWITCH	W85BNB	W85PCG or W	W85BSG or W	W85SNG or W	W85PBG or W	W85SBG or W	W85PGG or W	W85PSG or W
10A 1 GANG 1 WAY LARGE DOLLY PRESS SWITCH	W86BNB	W86PCG or W	W86BSG or W	W86SNG or W	W86PBG or W	W86SBG or W	W86PGG or W	W86PSG or W
10AX 2 GANG 1 WAY LARGE DOLLY SWITCH	W82BNB	W82PCG or W	W82BSG or W	W82SNG or W	W82PBG or W	W82SBG or W	W82PGG or W	W82PSG or W
10AX 2 GANG 1 WAY LARGE DOLLY SWITCH WITH NEON	W82LBNB	W82LPCG or W	W82LBSG or W	W82LSNG or W	W82LPBG or W	W82LSBG or W	W82LPGG or W	W82LPSG or W
10AX 2 GANG 2 WAY LARGE DOLLY SWITCH	W83BNB	W83PCG or W	W83BSG or W	W83SNG or W	W83PBG or W	W83SBG or W	W83PGG or W	W83PSG or W
10AX 2 GANG 2 WAY LARGE DOLLY SWITCH WITH NEON	W83LBNB	W83LPCG or W	W83LBSG or W	W83LSNG or W	W83LPBG or W	W83LSBG or W	W83LPGG or W	W83LPSG or W
10AX 4 GANG 1 WAY LARGE DOLLY SWITCH	W84BNB	W84PCG or W	W84BSG or W	W84SNG or W	W84PBG or W	W84SBG or W	W84PGG or W	W84PSG or W
10AX 4 GANG 1 WAY LARGE DOLLY SWITCH WITH NEON	W84LBNB	W84LPCG or W	W84LBSG or W	W84LSNG or W	W84LPBG or W	W84LSBG or W	W84LPGG or W	W84LPSG or W
10AX 4 GANG 2 WAY LARGE DOLLY SWITCH	W89BNB	W89PCG or W	W89BSG or W	W89SNG or W	W89PBG or W	W89SBG or W	W89PGG or W	W89PSG or W
10AX 4 GANG 2 WAY LARGE DOLLY SWITCH WITH NEON	W89LBNB	W89LPCG or W	W89LBSG or W	W89LSNG or W	W89LPBG or W	W89LSBG or W	W89LPGG or W	W89LPSG or W
20AX SP SWITCHES BS EN 60669 IEC 60669 SS 227 MS616								
20AX 1 GANG SINGLE POLE 1 WAY SWITCH	W011BNB	W011PCG or W	W011BSG or W	W011SNG or W	W011PBG or W	W011SBG or W	W011PGG or W	W011PSG or W
20AX 1 GANG SINGLE POLE 2 WAY SWITCH	W021BNB	W021PCG or W	W021BSG or W	W021SNG or W	W021PBG or W	W021SBG or W	W021PGG or W	W021PSG or W
20AX 2 GANG SINGLE POLE 1 WAY SWITCH	W031BNB	W031PCG or W	W031BSG or W	W031SNG or W	W031PBG or W	W031SBG or W	W031PGG or W	W031PSG or W
20AX 2 GANG SINGLE POLE 2 WAY SWITCH	W041BNB	W041PCG or W	W041BSG or W	W041SNG or W	W041PBG or W	W041SBG or W	W041PGG or W	W041PSG or W
20AX 3 GANG SINGLE POLE 1 WAY SWITCH	W051BNB	W051PCG or W	W051BSG or W	W051SNG or W	W051PBG or W	W051SBG or W	W051PGG or W	W051PSG or W
20AX 3 GANG SINGLE POLE 2 WAY SWITCH	W061BNB	W061PCG or W	W061BSG or W	W061SNG or W	W061PBG or W	W061SBG or W	W061PGG or W	W061PSG or W
20AX 4 GANG SINGLE POLE 1 WAY SWITCH	W411BNB	W411PCG or W	W411BSG or W	W411SNG or W	W411PBG or W	W411SBG or W	W411PGG or W	W411PSG or W
20AX 4 GANG SINGLE POLE 2 WAY SWITCH	W421BNB	W421PCG or W	W421BSG or W	W421SNG or W	W421PBG or W	W421SBG or W	W421PGG or W	W421PSG or W
20AX 6 GANG SINGLE POLE 1 WAY SWITCH	W431BNB	W431PCG or W	W431BSG or W	W431SNG or W	W431PBG or W	W431SBG or W	W431PGG or W	W431PSG or W
20AX 6 GANG SINGLE POLE 2 WAY SWITCH	W441BNB	W441PCG or W	W441BSG or W	W441SNG or W	W441PBG or W	W441SBG or W	W441PGG or W	W441PSG or W
20AX 1 GANG SINGLE POLE 1 WAY LARGE DOLLY SWITCH	W801BNB	W801PCG or W	W801BSG or W	W801SNG or W	W801PBG or W	W801SBG or W	W801PGG or W	W801PSG or W
20AX 1 GANG SINGLE POLE 1 WAY LARGE DOLLY SWITCH WITH NEON	W801LBNB	W801LPCG or W	W801LBSG or W	W801LSNG or W	W801LPBG or W	W801LSBG or W	W801LPGG or W	W801LPSG or W
20AX 1 GANG SINGLE POLE 2 WAY LARGE DOLLY SWITCH	W811BNB	W811PCG or W	W811BSG or W	W811SNG or W	W811PBG or W	W811SBG or W	W811PGG or W	W811PSG or W
20AX 1 GANG SINGLE POLE 2 WAY LARGE DOLLY SWITCH WITH NEON	W811LBNB	W811LPCG or W	W811LBSG or W	W811LSNG or W	W811LPBG or W	W811LSBG or W	W811LPGG or W	W811LPSG or W
20AX 2 GANG SINGLE POLE 1 WAY LARGE DOLLY SWITCH	W821BNB	W821PCG or W	W821BSG or W	W821SNG or W	W821PBG or W	W821SBG or W	W821PGG or W	W821PSG or W
20AX 2 GANG SINGLE POLE 1 WAY LARGE DOLLY SWITCH WITH NEON	W821LBNB	W821LPCG or W	W821LBSG or W	W821LSNG or W	W821LPBG or W	W821LSBG or W	W821LPGG or W	W821LPSG or W
20AX 2 GANG SINGLE POLE 2 WAY LARGE DOLLY SWITCH	W831BNB	W831PCG or W	W831BSG or W	W831SNG or W	W831PBG or W	W831SBG or W	W831PGG or W	W831PSG or W
20AX 2 GANG SINGLE POLE 2 WAY LARGE DOLLY SWITCH WITH NEON	W831LBNB	W831LPCG or W	W831LBSG or W	W831LSNG or W	W831LPBG or W	W831LSBG or W	W831LPGG or W	W831LPSG or W
20AX 4 GANG SINGLE POLE 1 WAY LARGE DOLLY SWITCH	W841BNB	W841PCG or W	W841BSG or W	W841SNG or W	W841PBG or W	W841SBG or W	W841PGG or W	W841PSG or W
20AX 4 GANG SINGLE POLE 1 WAY LARGE DOLLY SWITCH WITH NEON	W841LBNB	W841LPCG or W	W841LBSG or W	W841LSNG or W	W841LPBG or W	W841LSBG or W	W841LPGG or W	W841LPSG or W
20AX 4 GANG SINGLE POLE 2 WAY LARGE DOLLY SWITCH	W891BNB	W891PCG or W	W891BSG or W	W891SNG or W	W891PBG or W	W891SBG or W	W891PGG or W	W891PSG or W
20AX 4 GANG SINGLE POLE 2 WAY LARGE DOLLY SWITCH WITH NEON	W891LBNB	W891LPCG or W	W891LBSG or W	W891LSNG or W	W891LPBG or W	W891LSBG or W	W891LPGG or W	W891LPSG or W
20AX DP SWITCHES BS EN 60669 IEC 60669 SS 227 MS616								
20AX DOUBLE POLE SWITCH	W30BNB	W30PCG or W	W30BSG or W	W30SNG or W	W30PBG or W	W30SBG or W	W30PGG or W	W30PSG or W
20AX DOUBLE POLE SWITCH WITH NEON	W31BNB	W31PCG or W	W31BSG or W	W31SNG or W	W31PBG or W	W31SBG or W	W31PGG or W	W31PSG or W
20AX DOUBLE POLE SWITCH WITH FLEX OUTLET	W32BNB	W32PCG or W	W32BSG or W	W32SNG or W	W32PBG or W	W32SBG or W	W32PGG or W	W32PSG or W
20AX DOUBLE POLE SWITCH WITH FLEX OUTLET AND NEON	W33BNB	W33PCG or W	W33BSG or W	W33SNG or W	W33PBG or W	W33SBG or W	W33PGG or W	W33PSG or W
20AX DOUBLE POLE SWITCH MARKED WITH WATER HEATER	W30WHBNB	W30WHPCG or W	W30WHBSG or W	W30WHSNG or W	W30WHPBG or W	W30WHSBG or W	W30WHPGG or W	W30WHPSG or W
20AX DOUBLE POLE SWITCH WITH NEON MARKED WITH WATER HEATER	W31WHBNB	W31WHPCG or W	W31WHBSG or W	W31WHSNG or W	W31WHPBG or W	W31WHSBG or W	W31WHPGG or W	W31WHPSG or W
20AX DOUBLE POLE SWITCH WITH FLEX OUTLET MARKED WITH WATER HEATER	W32WHBNB	W32WHPCG or W	W32WHBSG or W	W32WHSNG or W	W32WHPBG or W	W32WHSBG or W	W32WHPGG or W	W32WHPSG or W
20AX DOUBLE POLE SWITCH WITH NEON AND FLEX OUTLET MARKED WITH WATER HEATER	W33WHBNB	W33WHPCG or W	W33WHBSG or W	W33WHSNG or W	W33WHPBG or W	W33WHSBG or W	W33WHPGG or W	W33WHPSG or W
20AX DOUBLE POLE LARGE DOLLY SWITCH WITH NEON	W87BNB	W87PCG or W	W87BSG or W	W87SNG or W	W87PBG or W	W87SBG or W	W87PGG or W	W87PSG or W
20AX 2GANG DOUBLE POLE LARGE DOLLY SWITCH WITH NEON	W88BNB	W88PCG or W	W88BSG or W	W88SNG or W	W88PBG or W	W88SBG or W	W88PGG or W	W88PSG or W
OUTLET CASING	W29 (MOULDING)							
13A FUSED CONNECTION UNITS & OUTLETS BS 1363/4								
13A SWITCHED FUSE CONNECTION UNIT	W60BNB	W60PCG or W	W60BSG or W	W60SNG or W	W60PBG or W	W60SBG or W	W60PGG or W	W60PSG or W
13A SWITCHED FUSE CONNECTION UNIT WITH NEON	W61BNB	W61PCG or W	W61BSG or W	W61SNG or W	W61PBG or W	W61SBG or W	W61PGG or W	W61PSG or W
13A SWITCHED FUSE CONNECTION UNIT WITH FLEX OUTLET	W62BNB	W62PCG or W	W62BSG or W	W62SNG or W	W62PBG or W	W62SBG or W	W62PGG or W	W62PSG or W
13A SWITCHED FUSE CONNECTION UNIT WITH NEON AND FLEX OUTLET	W63BNB	W63PCG or W	W63BSG or W	W63SNG or W	W63PBG or W	W63SBG or W	W63PGG or W	W63PSG or W
13A SWITCHED FUSE CONNECTION UNIT	W64BNB	W64PCG or W	W64BSG or W	W64SNG or W	W64PBG or W	W64SBG or W	W64PGG or W	W64PSG or W
13A SWITCHED FUSE CONNECTION UNIT WITH NEON	W65BNB	W65PCG or W	W65BSG or W	W65SNG or W	W65PBG or W	W65SBG or W	W65PGG or W	W65PSG or W
13A UNSWITCHED FUSE CONNECTION UNIT WITH FLEX OUTLET	W66BNB	W66PCG or W	W66BSG or W	W66SNG or W	W66PBG or W	W66SBG or W	W66PGG or W	W66PSG or W
13A UNSWITCHED FUSE CONNECTION UNIT WITH NEON AND FLEX OUTLET	W67BNB	W67PCG or W	W67BSG or W	W67SNG or W	W67PBG or W	W67SBG or W	W67PGG or W	W67PSG or W

45A SWITCHES BS EN 60669 IEC 60669								
45A SWITCH WITH NEON	W52BNB	W52PCG or W	W52BSG or W	W52SNG or W	W52PBG or W	W52SBG or W	W52PGG or W	W52PSG or W
45A SWITCH	W53BNB	W53PCG or W	W53BSG or W	W53SNG or W	W53PBG or W	W53SBG or W	W53PGG or W	W53PSG or W
45A RECTANGULAR SWITCH WITH NEON	W54BNB	W54PCG or W	W54BSG or W	W54SNG or W	W54PBG or W	W54SBG or W	W54PGG or W	W54PSG or W
45A RECTANGULAR SWITCH	W55BNB	W55PCG or W	W55BSG or W	W55SNG or W	W55PBG or W	W55SBG or W	W55PGG or W	W55PSG or W
13A SOCKET OUTLET BS 1363 SS 145 MS 589								
13A 1 GANG DOUBLE POLE SWITCHED SOCKET OUTLET	W13DPBNB	W13DPPCG or W	W13DPBSG or W	W13DPSNG or W	W13DPPBG or W	W13DPSBG or W	W13DPPGG or W	W13DPPSG or W
13A 1 GANG DOUBLE POLE SWITCHED SOCKET OUTLET WITH NEON	W14DPBNB	W14DPPCG or W	W14DPBSG or W	W14DPSNG or W	W14DPPBG or W	W14DPSBG or W	W14DPPGG or W	W14DPPSG or W
13A 1 GANG SINGLE POLE SWITCHED SOCKET OUTLET	W13SPBNB	W13SPPCG or W	W13SPBSG or W	W13SPSNG or W	W13SPPBG or W	W13SPSBG or W	W13SPPGG or W	W13SPPSG or W
13A 1 GANG SINGLE POLE SWITCHED SOCKET OUTLET WITH NEON	W14SPBNB	W14SPPCG or W	W14SPBSG or W	W14SPSNG or W	W14SPPBG or W	W14SPSBG or W	W14SPPGG or W	W14SPPSG or W
13A 2 GANG DOUBLE POLE SWITCHED SOCKET OUTLET	W23DPBNB	W23DPPCG or W	W23DPBSG or W	W23DPSNG or W	W23DPPBG or W	W23DPSBG or W	W23DPPGG or W	W23DPPSG or W
13A 2 GANG DOUBLE POLE SWITCHED SOCKET OUTLET WITH NEON	W24DPBNB	W24DPPCG or W	W24DPBSG or W	W24DPSNG or W	W24DPPBG or W	W24DPSBG or W	W24DPPGG or W	W24DPPSG or W
13A 2 GANG SINGLE POLE SWITCHED SOCKET OUTLET	W23SPBNB	W23SPPCG or W	W23SPBSG or W	W23SPSNG or W	W23SPPBG or W	W23SPSBG or W	W23SPPGG or W	W23SPPSG or W
13A 2 GANG SINGLE POLE SWITCHED SOCKET OUTLET WITH NEON	W24SPBNB	W24SPPCG or W	W24SPBSG or W	W24SPSNG or W	W24SPPBG or W	W24SPSBG or W	W24SPPGG or W	W24SPPSG or W
13A 1 GANG UNSWITCHED SOCKET OUTLET	W11BNB	W11PCG or W	W11BSG or W	W11SNG or W	W11PBG or W	W11SBG or W	W11PGG or W	W11PSG or W
13A 2 GANG UNSWITCHED SOCKET OUTLET	W12BNB	W12PCG or W	W12BSG or W	W12SNG or W	W12PBG or W	W12SBG or W	W12PGG or W	W12PSG or W
45A COOKER CONTROL UNIT BS 4177:1992								
45A COOKER CONTROL UNIT WITH NEON	W50BNB	W50PCG or W	W50BSG or W	W50SNG or W	W50PBG or W	W50SBG or W	W50PGG or W	W50PSG or W
45A COOKER CONTROL UNIT	W51BNB	W51PCG or W	W51BSG or W	W51SNG or W	W51PBG or W	W51SBG or W	W51PGG or W	W51PSG or W
2A,5A,15A SOCKET OUTLET BS 546 SS 472 MS 589								
2A 1 GANG UNSWITCHED SOCKET OUTLET	W12BNB	W12PCG or W	W12BSG or W	W12SNG or W	W12PBG or W	W12SBG or W	W12PGG or W	W12PSG or W
5A 1 GANG UNSWITCHED SOCKET OUTLET	W16BNB	W16PCG or W	W16BSG or W	W16SNG or W	W16PBG or W	W16SBG or W	W16PGG or W	W16PSG or W
5A 1 GANG SINGLE POLE SWITCHED SOCKET OUTLET	W56BNB	W56PCG or W	W56BSG or W	W56SNG or W	W56PBG or W	W56SBG or W	W56PGG or W	W56PSG or W
15A 1 GANG SINGLE POLE SWITCHED SOCKET OUTLET	W15BNB	W15PCG or W	W15BSG or W	W15SNG or W	W15PBG or W	W15SBG or W	W15PGG or W	W15PSG or W
15A 1 GANG UNSWITCHED SOCKET OUTLET	W57BNB	W57PCG or W	W57BSG or W	W57SNG or W	W57PBG or W	W57SBG or W	W57PGG or W	W57PSG or W
13A UNIVERSAL SOCKET BS 5733								
13A UNIVERSAL SOCKET	W18BNB	W18PCG or W	W18BSG or W	W18SNG or W	W18PBG or W	W18SBG or W	W18PGG or W	W18PSG or W
13A UNIVERSAL SOCKET WITH NEON	W19BNB	W19PCG or W	W19BSG or W	W19SNG or W	W18PBG or W	W19SBG or W	W19PGG or W	W19PSG or W
10A & 16A SOCKET OUTLET IEC 884-1								
10A 2 GANG EURO SOCKET	W17BNB	W17PCG or W	W17BSG or W	W17SNG or W	W17PBG or W	W17SBG or W	W17PGG or W	W17PSG or W
10A 2 PIN SWITCHED EURO SOCKET	W96BNB	W96PCG or W	W96BSG or W	W96SNG or W	W96PBG or W	W96SBG or W	W96PGG or W	W96PSG or W
16A GERMAN STYLE SOCKET OUTLET	W58BNB	W58PCG or W	W58BSG or W	W58SNG or W	W58PBG or W	W58SBG or W	W58PGG or W	W58PSG or W
BLANK PLATE BS 5733								
2 GANG BLANK PLATE	W98BNB	W98PCG or W	W98BSG or W	W98SNG or W	W98PBG or W	W98SBG or W	W98PGG or W	W98PSG or W
1 GANG BLANK PLATE	W99BNB	W99PCG or W	W99BSG or W	W99SNG or W	W99PBG or W	W99SBG or W	W99PGG or W	W99PSG or W
TELEPHONE & DATA OUTLETS/CO-AXIAL SOCKETS								
1 GANG NON-ISOLATED CO-AXIAL SOCKET	W70BNB	W70PCG or W	W70BSG or W	W70SNG or W	W70PBG or W	W70SBG or W	W70PGG or W	W70PSG or W
2 GANG NON-ISOLATED CO-AXIAL SOCKET	W71BNB	W71PCG or W	W71BSG or W	W71SNG or W	W71PBG or W	W71SBG or W	W71PGG or W	W71PSG or W
1 GANG ISOLATED CO-AXIAL SOCKET	W72BNB	W72PCG or W	W72BSG or W	W72SNG or W	W72PBG or W	W72SBG or W	W72PGG or W	W72PSG or W
2 GANG ISOLATED CO-AXIAL SOCKET	W73BNB	W73PCG or W	W73BSG or W	W73SNG or W	W73PBG or W	W73SBG or W	W73PGG or W	W73PSG or W
1 GANG F-TYPE SATELLITE SOCKET	W74BNB	W74PCG or W	W74BSG or W	W74SNG or W	W74PBG or W	W74SBG or W	W74PGG or W	W74PSG or W
2 GANG SATELLITE AND CO-AXIAL SOCKET	W75BNB	W75PCG or W	W75BSG or W	W75SNG or W	W75PBG or W	W75SBG or W	W75PGG or W	W75PSG or W
2 GANG DIPLEX TV & FM	W76BNB	W76PCG or W	W76BSG or W	W76SNG or W	W76PBG or W	W76SBG or W	W76PGG or W	W76PSG or W
3 GANG TRIPLEX SAT/TV/FM	W77BNB	W77PCG or W	W77BSG or W	W77SNG or W	W77PBG or W	W77SBG or W	W77PGG or W	W77PSG or W
TRIPLEX SAT/TV/FM + RETURN & 1 GANG TELEPHONE SOCKET	W78BNB	W78PCG or W	W78BSG or W	W78SNG or W	W78PBG or W	W78SBG or W	W78PGG or W	W78PSG or W
1 GANG SCREW CONNECTION TELEPHONE SOCKET,MASTER	W1BTMBNB	W1BTMPCG or W	W1BTMBSG or W	W1BTMSNG or W	W1BTMPBG or W	W1BTMSBG or W	W1BTMPGG or W	W1BTMPSG or W
2 GANG SCREW CONNECTION TELEPHONE SOCKET,MASTER	W2BTMBNB	W2BTMPCG or W	W2BTMBSG or W	W2BTMSNG or W	W2BTMPBG or W	W2BTMSBG or W	W2BTMPGG or W	W2BTMPSG or W
1 GANG SCREW CONNECTION TELEPHONE SOCKET,SLAVE	W1BTSBNB	W1BTSPCG or W	W1BTSBSG or W	W1BTSSNG or W	W1BTSPBG or W	W1BTSSBG or W	W1BTSPGG or W	W1BTSPSG or W
2 GANG SCREW CONNECTION TELEPHONE SOCKET,SLAVE	W2BTSBNB	W2BTSPCG or W	W2BTSBSG or W	W2BTSSNG or W	W2BTSPBG or W	W2BTSSBG or W	W2BTSPGG or W	W2BTSPSG or W
1 GANG SCREW CONNECTION TELEPHONE SOCKET,MASTER	W1BTMIBNB	W1BTMIPCG or W	W1BTMIBSG or W	W1BTMISNG or W	W1BTMIPBG or W	W1BTMISBG or W	W1BTMIPGG or W	W1BTMIPSG or W
2 GANG SCREW CONNECTION TELEPHONE SOCKET,MASTER	W2BTMIBNB	W2BTMIPCG or W	W2BTMIBSG or W	W2BTMISNG or W	W2BTMIPBG or W	W2BTMISBG or W	W2BTMIPGG or W	W2BTMIPSG or W
1 GANG TELEPHONE SOCKET,SLAVE	W1BTSIBNB	W1BTSIPCG or W	W1BTSIBSG or W	W1BTSISNG or W	W1BTSIPBG or W	W1BTSISBG or W	W1BTSIPGG or W	W1BTSIPSG or W
2 GANG TELEPHONE SOCKET,SLAVE	W2BTSIBNB	W2BTSIPCG or W	W2BTSIBSG or W	W2BTSISNG or W	W2BTSIPBG or W	W2BTSISBG or W	W2BTSIPGG or W	W2BTSIPSG or W
1 GANG WITH ID RJ45 DATA OUTLET SOCKET	W1RJ45BNB	W1RJ45PCG or W	W1RJ45BSG or W	W1RJ45SNG or W	W1RJ45PBG or W	W1RJ45SBG or W	W1RJ45PGG or W	W1RJ45PSG or W
2 GANG WITH ID RJ45 DATA OUTLET SOCKET	W2RJ45BNB	W2RJ45PCG or W	W2RJ45BSG or W	W2RJ45SNG or W	W2RJ45PBG or W	W2RJ45SBG or W	W2RJ45PGG or W	W2RJ45PSG or W
1 GANG WITH ID RJ11 DATA OUTLET SOCKET	W1RJ11BNB	W1RJ11PCG or W	W1RJ11BSG or W	W1RJ11SNG or W	W1RJ11PBG or W	W1RJ11SBG or W	W1RJ11PGG or W	W1RJ11PSG or W
2 GANG WITH ID RJ11 DATA OUTLET SOCKET	W2RJ11BNB	W2RJ11PCG or W	W2RJ11BSG or W	W2RJ11SNG or W	W2RJ11PBG or W	W2RJ11SBG or W	W2RJ11PGG or W	W2RJ11PSG or W
DIMMER SWITCHES(PUSH ON/OFF)								
1 GANG 2 WAY-PUSH ON/OFF DIMMER SWITCH	W90BNB	W90PCG or W	W90BSG or W	W90SNG or W	W90PBG or W	W90SBG or W	W90PGG or W	W90PSG or W
2 GANG 2 WAY-PUSH ON/OFF DIMMER SWITCH	W91BNB	W91PCG or W	W91BSG or W	W91SNG or W	W91PBG or W	W91SBG or W	W91PGG or W	W91PSG or W
3 GANG 2 WAY-PUSH ON/OFF DIMMER SWITCH	W92BNB	W92PCG or W	W92BSG or W	W92SNG or W	W92PBG or W	W92SBG or W	W92PGG or W	W92PSG or W
4 GANG 2 WAY-PUSH ON/OFF DIMMER SWITCH	W93BNB	W93PCG or W	W93BSG or W	W93SNG or W	W93PBG or W	W93SBG or W	W93PGG or W	W93PSG or W
HOTELS BS EN 61558 IP41								
DO NOT DISTURB/PLEASE CLEAN UP/10A BELL SWITCH	WH90BNB	WH90PCG or W	WH90BSG or W	WH90SNG or W	WH90PBG or W	WH90SBG or W	WH90PGG or W	WH90PSG or W
16A ENERGY SAVING SWITCH WITH NEON(IT MAY DELAY 30 SECONDS)	WH91BNB	WH91PCG or W	WH91BSG or W	WH91SNG or W	WH91PBG or W	WH91SBG or W	WH91PGG or W	WH91PSG or W
BELL BUZZER	WH92BNB	WH92PCG or W	WH92BSG or W	WH92SNG or W	WH92PBG or W	WH92SBG or W	WH92PGG or W	WH92PSG or W
DO NOT DISTURB/PLEASE CLEAN UP/10A SWITCH	WH93BNB	WH93PCG or W	WH93BSG or W	WH93SNG or W	WH93PBG or W	WH93SBG or W	WH93PGG or W	WH93PSG or W
115/230V DUAL VOLTAGE SHAVER SOCKET	W21BNB	W21PCG or W	W21BSG or W	W21SNG or W	W21PBG or W	W21SBG or W	W21PGG or W	W21PSG or W

Metalica DESIGNERS' TOP CHOICE

Metalica is an elegant range of wiring accessories with an unrivaled 3.5mm ultra slim metallic front plate. Designed for quick and easy installation, you have a choice of either Contemporary or Modern look.
Metalica is made from high quality material, the front plate is coated with a scratch resistance lacquer finish.
With all the above advantages and coupled with a 12 years product warranty, there's no doubt that Metalica is the Designers' Top Choice.

» Main Features:



1. Unique and stylish profile

2. Ultra slim front plate of only 3.5mm

3. Choice of Eight High Quality Finishes

BLACK NICKEL

POLISHED CHROME

BRUSHED STEEL

SATIN NICKEL

POLISHED BRASS

SATIN BRASS

PURE GOLD

PURE SILVER

4. Choice of Colour Inserts



WHITE INSERT

GREY INSERT

BLACK INSERT

5. Neon indicator on top of rocker for good visibility



7. Terminal screws are held captive within the terminal housing

6. Plastic separator for additional protection

8. 90 degrees cable entry for quick and easy installation

OFFICE ENVIRONMENT

RESIDENTS, RESORTS OR HOTELS

OUTDOOR PREMISES

45A SWITCHES BS EN 60669 IEC 60669								
45A SWITCH WITH NEON	N52BNB	N52PCG or W	N52BSG or W	N52SNG or W	N52PBG or W	N52SBG or W	N52PGG or W	N52PSG or W
45A SWITCH	N53BNB	N53PCG or W	N53BSG or W	N53SNG or W	N53PBG or W	N53SBG or W	N53PGG or W	N53PSG or W
45A RECTANGULAR SWITCH WITH NEON	N54BNB	N54PCG or W	N54BSG or W	N54SNG or W	N54PBG or W	N54SBG or W	N54PGG or W	N54PSG or W
45A RECTANGULAR SWITCH	N55BNB	N55PCG or W	N55BSG or W	N55SNG or W	N55PBG or W	N55SBG or W	N55PGG or W	N55PSG or W
13A SOCKET OUTLET BS 1363 SS 145 MS 589								
13A 1 GANG DOUBLE POLE SWITCHED SOCKET OUTLET	N13DPBNB	N13DPPCG or W	N13DPBSG or W	N13DPSNG or W	N13DPPBG or W	N13DPSBG or W	N13DPPGG or W	N13DPPSG or W
13A 1 GANG DOUBLE POLE SWITCHED SOCKET OUTLET WITH NEON	N14DPBNB	N14DPPCG or W	N14DPBSG or W	N14DPSNG or W	N14DPPBG or W	N14DPSBG or W	N14DPPGG or W	N14DPPSG or W
13A 1 GANG SINGLE POLE SWITCHED SOCKET OUTLET	N13SPBNB	N13SPPCG or W	N13SPBSG or W	N13SPSNG or W	N13SPPBG or W	N13SPSBG or W	N13SPPGG or W	N13SPPSG or W
13A 1 GANG SINGLE POLE SWITCHED SOCKET OUTLET WITH NEON	N14SPBNB	N14SPPCG or W	N14SPBSG or W	N14SPSNG or W	N14SPPBG or W	N14SPSBG or W	N14SPPGG or W	N14SPPSG or W
13A 2 GANG DOUBLE POLE SWITCHED SOCKET OUTLET	N23DPBNB	N23DPPCG or W	N23DPBSG or W	N23DPSNG or W	N23DPPBG or W	N23DPSBG or W	N23DPPGG or W	N23DPPSG or W
13A 2 GANG DOUBLE POLE SWITCHED SOCKET OUTLET WITH NEON	N24DPBNB	N24DPPCG or W	N24DPBSG or W	N24DPSNG or W	N24DPPBG or W	N24DPSBG or W	N24DPPGG or W	N24DPPSG or W
13A 2 GANG SINGLE POLE SWITCHED SOCKET OUTLET	N23SPBNB	N23SPPCG or W	N23SPBSG or W	N23SPSNG or W	N23SPPBG or W	N23SPSBG or W	N23SPPGG or W	N23SPPSG or W
13A 2 GANG SINGLE POLE SWITCHED SOCKET OUTLET WITH NEON	N24SPBNB	N24SPPCG or W	N24SPBSG or W	N24SPSNG or W	N24SPPBG or W	N24SPSBG or W	N24SPPGG or W	N24SPPSG or W
13A 1 GANG UNSWITCHED SOCKET OUTLET	N11BNB	N11PCG or W	N11BSG or W	N11SNG or W	N11PBG or W	N11SBG or W	N11PGG or W	N11PSG or W
13A 2 GANG UNSWITCHED SOCKET OUTLET	N12BNB	N12PCG or W	N12BSG or W	N12SNG or W	N12PBG or W	N12SBG or W	N12PGG or W	N12PSG or W
45A COOKER CONTROL UNIT BS 4177:1992								
45A COOKER CONTROL UNIT WITH NEON	N50BNB	N50PCG or W	N50BSG or W	N50SNG or W	N50PBG or W	N50SBG or W	N50PGG or W	N50PSG or W
45A COOKER CONTROL UNIT	N51BNB	N51PCG or W	N51BSG or W	N51SNG or W	N51PBG or W	N51SBG or W	N51PGG or W	N51PSG or W
2A,5A,15A SOCKET OUTLET BS 546 SS 472 MS 589								
2A 1 GANG UNSWITCHED SOCKET OUTLET	N12BNB	N12PCG or W	N12BSG or W	N12SNG or W	N12PBG or W	N12SBG or W	N12PGG or W	N12PSG or W
5A 1 GANG UNSWITCHED SOCKET OUTLET	N16BNB	N16PCG or W	N16BSG or W	N16SNG or W	N16PBG or W	N16SBG or W	N16PGG or W	N16PSG or W
5A 1 GANG SINGLE POLE SWITCHED SOCKET OUTLET	N56BNB	N56PCG or W	N56BSG or W	N56SNG or W	N56PBG or W	N56SBG or W	N56PGG or W	N56PSG or W
15A 1 GANG SINGLE POLE SWITCHED SOCKET OUTLET	N15BNB	N15PCG or W	N15BSG or W	N15SNG or W	N15PBG or W	N15SBG or W	N15PGG or W	N15PSG or W
15A 1 GANG UNSWITCHED SOCKET OUTLET	N57BNB	N57PCG or W	N57BSG or W	N57SNG or W	N57PBG or W	N57SBG or W	N57PGG or W	N57PSG or W
13A UNIVERSAL SOCKET BS 5733								
13A UNIVERSAL SOCKET	N18BNB	N18PCG or W	N18BSG or W	N18SNG or W	N18PBG or W	N18SBG or W	N18PGG or W	N18PSG or W
13A UNIVERSAL SOCKET WITH NEON	N19BNB	N19PCG or W	N19BSG or W	N19SNG or W	N18PBG or W	N19SBG or W	N19PGG or W	N19PSG or W
10A & 16A SOCKET OUTLET IEC 884-1								
10A 2 GANG EURO SOCKET	N17BNB	N17PCG or W	N17BSG or W	N17SNG or W	N17PBG or W	N17SBG or W	N17PGG or W	N17PSG or W
10A 2 PIN SWITCHED EURO SOCKET	N96BNB	N96PCG or W	N96BSG or W	N96SNG or W	N96PBG or W	N96SBG or W	N96PGG or W	N96PSG or W
16A GERMAN STYLE SOCKET OUTLET	N58BNB	N58PCG or W	N58BSG or W	N58SNG or W	N58PBG or W	N58SBG or W	N58PGG or W	N58PSG or W
BLANK PLATE BS 5733								
2 GANG BLANK PLATE	N98BNB	N98PCG or W	N98BSG or W	N98SNG or W	N98PBG or W	N98SBG or W	N98PGG or W	N98PSG or W
1 GANG BLANK PLATE	N99BNB	N99PCG or W	N99BSG or W	N99SNG or W	N99PBG or W	N99SBG or W	N99PGG or W	N99PSG or W
TELEPHONE & DATA OUTLETS/CO-AXIAL SOCKETS								
1 GANG NON-ISOLATED CO-AXIAL SOCKET	N70BNB	N70PCG or W	N70BSG or W	N70SNG or W	N70PBG or W	N70SBG or W	N70PGG or W	N70PSG or W
2 GANG NON-ISOLATED CO-AXIAL SOCKET	N71BNB	N71PCG or W	N71BSG or W	N71SNG or W	N71PBG or W	N71SBG or W	N71PGG or W	N71PSG or W
1 GANG ISOLATED CO-AXIAL SOCKET	N72BNB	N72PCG or W	N72BSG or W	N72SNG or W	N72PBG or W	N72SBG or W	N72PGG or W	N72PSG or W
2 GANG ISOLATED CO-AXIAL SOCKET	N73BNB	N73PCG or W	N73BSG or W	N73SNG or W	N73PBG or W	N73SBG or W	N73PGG or W	N73PSG or W
1 GANG F-TYPE SATELLITE SOCKET	N74BNB	N74PCG or W	N74BSG or W	N74SNG or W	N74PBG or W	N74SBG or W	N74PGG or W	N74PSG or W
2 GANG SATELLITE AND CO-AXIAL SOCKET	N75BNB	N75PCG or W	N75BSG or W	N75SNG or W	N75PBG or W	N75SBG or W	N75PGG or W	N75PSG or W
2 GANG DIPLEX TV & FM	N76BNB	N76PCG or W	N76BSG or W	N76SNG or W	N76PBG or W	N76SBG or W	N76PGG or W	N76PSG or W
3 GANG TRIPLEX SAT/TV/FM	N77BNB	N77PCG or W	N77BSG or W	N77SNG or W	W77PBG or W	N77SBG or W	N77PGG or W	N77PSG or W
TRIPLEX SAT/TV/FM + RETURN & 1 GANG TELEPHONE SOCKET	N78BNB	N78PCG or W	N78BSG or W	N78SNG or W	N78PBG or W	N78SBG or W	N78PGG or W	N78PSG or W
1 GANG SCREW CONNECTION TELEPHONE SOCKET,MASTER	N1BTMBNB	N1BTMPCG or W	N1BTMBSG or W	N1BTMSNG or W	N1BTMPBG or W	N1BTMSBG or W	N1BTMPGG or W	N1BTMPSG or W
2 GANG SCREW CONNECTION TELEPHONE SOCKET,MASTER	N2BTMBNB	N2BTMPCG or W	N2BTMBSG or W	N2BTMSNG or W	N2BTMPBG or W	N2BTMSBG or W	N2BTMPGG or W	N2BTMPSG or W
1 GANG SCREW CONNECTION TELEPHONE SOCKET,SLAVE	N1BTSBNB	N1BTSPCG or W	N1BTSBSG or W	N1BTSSNG or W	N1BTSPBG or W	N1BTSSBG or W	N1BTSPGG or W	N1BTSPSG or W
2 GANG SCREW CONNECTION TELEPHONE SOCKET,SLAVE	N2BTSBNB	N2BTSPCG or W	N2BTSBSG or W	N2BTSSNG or W	N2BTSPBG or W	N2BTSSBG or W	N2BTSPGG or W	N2BTSPSG or W
1 GANG SCREW CONNECTION TELEPHONE SOCKET,MASTER	N1BTMIBNB	N1BTMIPCG or W	N1BTMIBSG or W	N1BTMISNG or W	N1BTMIPBG or W	N1BTMISBG or W	N1BTMIPGG or W	N1BTMIPSG or W
2 GANG SCREW CONNECTION TELEPHONE SOCKET,MASTER	N2BTMIBNB	N2BTMIPCG or W	N2BTMIBSG or W	N2BTMISNG or W	N2BTMIPBG or W	N2BTMISBG or W	N2BTMIPGG or W	N2BTMIPSG or W
1 GANG TELEPHONE SOCKET,SLAVE	N1BTSIBNB	N1BTSIPCG or W	N1BTSIBSG or W	N1BTSISNG or W	N1BTSIPBG or W	N1BTSISBG or W	N1BTSIPGG or W	N1BTSIPSG or W
2 GANG TELEPHONE SOCKET,SLAVE	N2BTSIBNB	N2BTSIPCG or W	N2BTSIBSG or W	N2BTSISNG or W	N2BTSIPBG or W	N2BTSISBG or W	N2BTSIPGG or W	N2BTSIPSG or W
1 GANG WITH ID RJ45 DATA OUTLET SOCKET	N1RJ45BNB	N1RJ45PCG or W	N1RJ45BSG or W	N1RJ45SNG or W	N1RJ45PBG or W	N1RJ45SBG or W	N1RJ45PGG or W	N1RJ45PSG or W
2 GANG WITH ID RJ45 DATA OUTLET SOCKET	N2RJ45BNB	N2RJ45PCG or W	N2RJ45BSG or W	N2RJ45SNG or W	N2RJ45PBG or W	N2RJ45SBG or W	N2RJ45PGG or W	N2RJ45PSG or W
1 GANG WITH ID RJ11 DATA OUTLET SOCKET	N1RJ11BNB	N1RJ11PCG or W	N1RJ11BSG or W	N1RJ11SNG or W	N1RJ11PBG or W	N1RJ11SBG or W	N1RJ11PGG or W	N1RJ11PSG or W
2 GANG WITH ID RJ11 DATA OUTLET SOCKET	N2RJ11BNB	N2RJ11PCG or W	N2RJ11BSG or W	N2RJ11SNG or W	N2RJ11PBG or W	N2RJ11SBG or W	N2RJ11PGG or W	N2RJ11PSG or W
DIMMER SWITCHES(PUSH ON/OFF)								
1 GANG 2 WAY-PUSH ON/OFF DIMMER SWITCH	N90BNB	N90PCG or W	N90BSG or W	N90SNG or W	N90PBG or W	N90SBG or W	N90PGG or W	N90PSG or W
2 GANG 2 WAY-PUSH ON/OFF DIMMER SWITCH	N91BNB	N91PCG or W	N91BSG or W	N91SNG or W	N91PBG or W	N91SBG or W	N91PGG or W	N91PSG or W
3 GANG 2 WAY-PUSH ON/OFF DIMMER SWITCH	N92BNB	N92PCG or W	N92BSG or W	N92SNG or W	N92PBG or W	N92SBG or W	N92PGG or W	N92PSG or W
4 GANG 2 WAY-PUSH ON/OFF DIMMER SWITCH	N93BNB	N93PCG or W	N93BSG or W	N93SNG or W	N93PBG or W	N93SBG or W	N93PGG or W	N93PSG or W
HOTELS BS EN 61558 IP41								
DO NOT DISTURB/PLEASE CLEAN UP/10A BELL SWITCH	NH90BNB	NH90PCG or W	NH90BSG or W	NH90SNG or W	NH90PBG or W	NH90SBG or W	NH90PGG or W	NH90PSG or W
BELL BUZZER	NH92BNB	NH92PCG or W	NH92BSG or W	NH92SNG or W	NH92PBG or W	NH92SBG or W	NH92PGG or W	NH92PSG or W
DO NOT DISTURB/PLEASE CLEAN UP/10A SWITCH	NH93BNB	NH93PCG or W	NH93BSG or W	NH93SNG or W	NH93PBG or W	NH93SBG or W	NH93PGG or W	NH93PSG or W
115/230V DUAL VOLTAGE SHAVER SOCKET	N21BNB	N21PCG or W	N21BSG or W	N21SNG or W	N21PBG or W	N21SBG or W	N21PGG or W	N21PSG or W

DESCRIPTION	BLACK NICKEL	POLISHED CHROME	BRUSHED STEEL	SATIN NICKEL	POLISHED BRASS	SATIN BRASS	PURE GOLD	PURE SILVER
10AX SWITCHES BS EN 60669 IEC 60669 SS 227 MS616								
10AX 1 GANG 1 WAY SWITCH	N01BNB	N01PCG or W	N01BSG or W	N01SNG or W	N01PBG or W	N01SBG or W	N01PGG or W	N01PSG or W
10AX 1 GANG 2 WAY SWITCH	N02BNB	N02PCG or W	N02BSG or W	N02SNG or W	N02PBG or W	N02SBG or W	N02PGG or W	N02PSG or W
10A 1 GANG 1 WAY BELL SWITCH	N07BNB	N07PCG or W	N07BSG or W	N07SNG or W	N07PBG or W	N07SBG or W	N07PGG or W	N07PSG or W
10A 1GANG 1 WAY PRESS SWITCH	N08BNB	N08PCG or W	N08BSG or W	N08SNG or W	N08PBG or W	N08SBG or W	N08PGG or W	N08PSG or W
10AX INTERMEDIATE SWITCH	N10BNB	N10PCG or W	N10BSG or W	N10SNG or W	N10PBG or W	N10SBG or W	N10PGG or W	N10PSG or W
CHROME 3 POLE FAN ISOLATOR SWITCH	N09BNB	N09PCG or W	N09BSG or W	N09SNG or W	N09PBG or W	N09SBG or W	N09PGG or W	N09PSG or W
10AX 2 GANG 1 WAY SWITCH	N03BNB	N03PCG or W	N03BSG or W	N03SNG or W	N03PBG or W	N03SBG or W	N03PGG or W	N03PSG or W
10AX 2 GANG 2 WAY SWITCH	N04BNB	N04PCG or W	N04BSG or W	N04SNG or W	N04PBG or W	N04SBG or W	N04PGG or W	N04PSG or W
10AX 3 GANG 1 WAY SWITCH	N05BNB	N05PCG or W	N05BSG or W	N05SNG or W	N05PBG or W	N05SBG or W	N05PGG or W	N05PSG or W
10AX 3 GANG 2 WAY SWITCH	N06BNB	N06PCG or W	N06BSG or W	N06SNG or W	N06PBG or W	N06SBG or W	N06PGG or W	N06PSG or W
10AX 4 GANG 1 WAY SWITCH	N41BNB	N41PCG or W	N41BSG or W	N41SNG or W	N41PBG or W	N41SBG or W	N41PGG or W	N41PSG or W
10AX 4 GANG 2 WAY SWITCH	N42BNB	N42PCG or W	N42BSG or W	N42SNG or W	N42PBG or W	N42SBG or W	N42PGG or W	N42PSG or W
10AX 6 GANG 1 WAY SWITCH	N43BNB	N43PCG or W	N43BSG or W	N43SNG or W	N43PBG or W	N43SBG or W	N43PGG or W	N43PSG or W
10AX 6 GANG 2 WAY SWITCH	N44BNB	N44PCG or W	N44BSG or W	N44SNG or W	N44PBG or W	N44SBG or W	N44PGG or W	N44PSG or W
10AX 1 GANG 1 WAY LARGE DOLLY SWITCH	N80BNB	N80PCG or W	N80BSG or W	N80SNG or W	N80PBG or W	N80SBG or W	N80PGG or W	N80PSG or W
10AX 1 GANG 1 WAY LARGE DOLLY SWITCH WITH NEON	N80LBNB	N80LPCG or W	N80LBSG or W	N80LSNG or W	N80LPBG or W	N80LSBG or W	N80LPGG or W	N80LPSG or W
10AX 1 GANG 2 WAY LARGE DOLLY SWITCH	N81BNB	N81PCG or W	N81BSG or W	N81SNG or W	N81PBG or W	N81SBG or W	N81PGG or W	N81PSG or W
10AX 1 GANG 2 WAY LARGE DOLLY SWITCH WITH NEON	N81LBNB	N81LPCG or W	N81LBSG or W	N81LSNG or W	N81LPBG or W	N81LSBG or W	N81LPGG or W	N81LPSG or W
10A 1 GANG 1 WAY LARGE DOLLY BELL SWITCH	N85BNB	N85PCG or W	N85BSG or W	N85SNG or W	N85PBG or W	N85SBG or W	N85PGG or W	N85PSG or W
10A 1 GANG 1 WAY LARGE DOLLY PRESS SWITCH	N86BNB	N86PCG or W	N86BSG or W	N86SNG or W	N86PBG or W	N86SBG or W	N86PGG or W	N86PSG or W
10AX 2 GANG 1 WAY LARGE DOLLY SWITCH	N82BNB	N82PCG or W	N82BSG or W	N82SNG or W	N82PBG or W	N82SBG or W	N82PGG or W	N82PSG or W
10AX 2 GANG 1 WAY LARGE DOLLY SWITCH WITH NEON	N82LBNB	N82LPCG or W	N82LBSG or W	N82LSNG or W	N82LPBG or W	N82LSBG or W	N82LPGG or W	N82LPSG or W
10AX 2 GANG 2 WAY LARGE DOLLY SWITCH	N83BNB	N83PCG or W	N83BSG or W	N83SNG or W	N83PBG or W	N83SBG or W	N83PGG or W	N83PSG or W
10AX 2 GANG 2 WAY LARGE DOLLY SWITCH WITH NEON	N83LBNB	N83LPCG or W	N83LBSG or W	N83LSNG or W	N83LPBG or W	N83LSBG or W	N83LPGG or W	N83LPSG or W
10AX 4 GANG 1 WAY LARGE DOLLY SWITCH	N84BNB	N84PCG or W	N84BSG or W	N84SNG or W	N84PBG or W	N84SBG or W	N84PGG or W	N84PSG or W
10AX 4 GANG 1 WAY LARGE DOLLY SWITCH WITH NEON	N84LBNB	N84LPCG or W	N84LBSG or W	N84LSNG or W	N84LPBG or W	N84LSBG or W	N84LPGG or W	N84LPSG or W
10AX 4 GANG 2 WAY LARGE DOLLY SWITCH	N89BNB	N89PCG or W	N89BSG or W	N89SNG or W	N89PBG or W	N89SBG or W	N89PGG or W	N89PSG or W
10AX 4 GANG 2 WAY LARGE DOLLY SWITCH WITH NEON	N89LBNB	N89LPCG or W	N89LBSG or W	N89LSNG or W	N89LPBG or W	N89LSBG or W	N89LPGG or W	N89LPSG or W
20AX SP SWITCHES BS EN 60669 IEC 60669 SS 227 MS616								
20AX 1 GANG SINGLE POLE 1 WAY SWITCH	N011BNB	N011PCG or W	N011BSG or W	N011SNG or W	N011PBG or W	N011SBG or W	N011PGG or W	N011PSG or W
20AX 1 GANG SINGLE POLE 2 WAY SWITCH	N021BNB	N021PCG or W	N021BSG or W	N021SNG or W	N021PBG or W	N021SBG or W	N021PGG or W	N021PSG or W
20AX 2 GANG SINGLE POLE 1 WAY SWITCH	N031BNB	N031PCG or W	N031BSG or W	N031SNG or W	N031PBG or W	N031SBG or W	N031PGG or W	N031PSG or W
20AX 2 GANG SINGLE POLE 2 WAY SWITCH	N041BNB	N041PCG or W	N041BSG or W	N041SNG or W	N041PBG or W	N041SBG or W	N041PGG or W	N041PSG or W
20AX 3 GANG SINGLE POLE 1 WAY SWITCH	N051BNB	N051PCG or W	N051BSG or W	N051SNG or W	N051PBG or W	N051SBG or W	N051PGG or W	N051PSG or W
20AX 3 GANG SINGLE POLE 2 WAY SWITCH	N061BNB	N061PCG or W	N061BSG or W	N061SNG or W	N061PBG or W	N061SBG or W	N061PGG or W	N061PSG or W
20AX 4 GANG SINGLE POLE 1 WAY SWITCH	N411BNB	N411PCG or W	N411BSG or W	N411SNG or W	N411PBG or W	N411SBG or W	N411PGG or W	N411PSG or W
20AX 4 GANG SINGLE POLE 2 WAY SWITCH	N421BNB	N421PCG or W	N421BSG or W	N421SNG or W	N421PBG or W	N421SBG or W	N421PGG or W	N421PSG or W
20AX 6 GANG SINGLE POLE 1 WAY SWITCH	N431BNB	N431PCG or W	N431BSG or W	N431SNG or W	N431PBG or W	N431SBG or W	N431PGG or W	N431PSG or W
20AX 6 GANG SINGLE POLE 2 WAY SWITCH	N441BNB	N441PCG or W	N441BSG or W	N441SNG or W	N441PBG or W	N441SBG or W	N441PGG or W	N441PSG or W
20AX 1 GANG SINGLE POLE 1 WAY LARGE DOLLY SWITCH	N801BNB	N801PCG or W	N801BSG or W	N801SNG or W	N801PBG or W	N801SBG or W	N801PGG or W	N801PSG or W
20AX 1 GANG SINGLE POLE 1 WAY LARGE DOLLY SWITCH WITH NEON	N801LBNB	N801LPCG or W	N801LBSG or W	N801LSNG or W	N801LPBG or W	N801LSBG or W	N801LPGG or W	N801LPSG or W
20AX 1 GANG SINGLE POLE 2 WAY LARGE DOLLY SWITCH	N811BNB	N811PCG or W	N811BSG or W	N811SNG or W	N811PBG or W	N811SBG or W	N811PGG or W	N811PSG or W
20AX 1 GANG SINGLE POLE 2 WAY LARGE DOLLY SWITCH WITH NEON	N811LBNB	N811LPCG or W	N811LBSG or W	N811LSNG or W	N811LPBG or W	N811LSBG or W	N811LPGG or W	N811LPSG or W
20AX 2 GANG SINGLE POLE 1 WAY LARGE DOLLY SWITCH	W821BNB	N821PCG or W	N821BSG or W	N821SNG or W	N821PBG or W	N821SBG or W	N821PGG or W	N821PSG or W
20AX 2 GANG SINGLE POLE 1 WAY LARGE DOLLY SWITCH WITH NEON	N821LBNB	N821LPCG or W	N821LBSG or W	N821LSNG or W	N821LPBG or W	N821LSBG or W	N821LPGG or W	N821LPSG or W
20AX 2 GANG SINGLE POLE 2 WAY LARGE DOLLY SWITCH	N831BNB	N831PCG or W	N831BSG or W	N831SNG or W	N831PBG or W	N831SBG or W	N831PGG or W	N831PSG or W
20AX 2 GANG SINGLE POLE 2 WAY LARGE DOLLY SWITCH WITH NEON	N831LBNB	N831LPCG or W	N831LBSG or W	N831LSNG or W	N831LPBG or W	N831LSBG or W	N831LPGG or W	N831LPSG or W
20AX 4 GANG SINGLE POLE 1 WAY LARGE DOLLY SWITCH	N841BNB	N841PCG or W	N841BSG or W	N841SNG or W	N841PBG or W	N841SBG or W	N841PGG or W	N841PSG or W
20AX 4 GANG SINGLE POLE 1 WAY LARGE DOLLY SWITCH WITH NEON	N841LBNB	N841LPCG or W	N841LBSG or W	N841LSNG or W	N841LPBG or W	N841LSBG or W	N841LPGG or W	N841LPSG or W
20AX 4 GANG SINGLE POLE 2 WAY LARGE DOLLY SWITCH	N891BNB	N891PCG or W	N891BSG or W	N891SNG or W	N891PBG or W	N891SBG or W	N891PGG or W	N891PSG or W
20AX 4 GANG SINGLE POLE 2 WAY LARGE DOLLY SWITCH WITH NEON	N891LBNB	N891LPCG or W	N891LBSG or W	N891LSNG or W	N891LPBG or W	N891LSBG or W	N891LPGG or W	N891LPSG or W
20AX DP SWITCHES BS EN 60669 IEC 60669 SS 227 MS616								
20AX DOUBLE POLE SWITCH	N30BNB	N30PCG or W	N30BSG or W	N30SNG or W	N30PBG or W	N30SBG or W	N30PGG or W	N30PSG or W
20AX DOUBLE POLE SWITCH WITH NEON	N31BNB	N31PCG or W	N31BSG or W	N31SNG or W	N31PBG or W	N31SBG or W	N31PGG or W	N31PSG or W
20AX DOUBLE POLE SWITCH WITH FLEX OUTLET	N32BNB	N32PCG or W	N32BSG or W	N32SNG or W	N32PBG or W	N32SBG or W	N32PGG or W	N32PSG or W
20AX DOUBLE POLE SWITCH WITH FLEX OUTLET AND NEON	N33BNB	N33PCG or W	N33BSG or W	N33SNG or W	N33PBG or W	N33SBG or W	N33PGG or W	N33PSG or W
20AX DOUBLE POLE SWITCH MARKED WITH WATER HEATER	N30WHBNB	N30WHPCG or W	N30WHBSG or W	N30WHSNG or W	N30WHPBG or W	N30WHSBG or W	N30WHPGG or W	N30WHPSG or W
20AX DOUBLE POLE SWITCH WITH NEON MARKED WITH WATER HEATER	N31WHBNB	N31WHPCG or W	N31WHBSG or W	N31WHSNG or W	N31WHPBG or W	N31WHSBG or W	N31WHPGG or W	N31WHPSG or W
20AX DOUBLE POLE SWITCH WITH FLEX OUTLET MARKED WITH WATER HEATER	N32WHBNB	N32WHPCG or W	N32WHBSG or W	N32WHSNG or W	N32WHPBG or W	N32WHSBG or W	N32WHPGG or W	N32WHPSG or W
20AX DOUBLE POLE SWITCH WITH NEON AND FLEX OUTLET MARKED WITH WATER HEATER	N33WHBNB	N33WHPCG or W	N33WHBSG or W	N33WHSNG or W	N33WHPBG or W	N33WHSBG or W	N33WHPGG or W	N33WHPSG or W
20AX DOUBLE POLE LARGE DOLLY SWITCH WITH NEON	N87BNB	N87PCG or W	N87BSG or W	N87SNG or W	N87PBG or W	N87SBG or W	N87PGG or W	N87PSG or W
20AX 2GANG DOUBLE POLE LARGE DOLLY SWITCH WITH NEON	N88BNB	N88PCG or W	N88BSG or W	N88SNG or W	N88PBG or W	N88SBG or W	N88PGG or W	N88PSG or W
13A FUSED CONNECTION UNITS & OUTLETS BS 1363/4								
13A SWITCHED FUSE CONNECTION UNIT	N60BNB	N60PCG or W	N60BSG or W	N60SNG or W	N60PBG or W	N60SBG or W	N60PGG or W	N60PSG or W
13A SWITCHED FUSE CONNECTION UNIT WITH NEON	N61BNB	N61PCG or W	N61BSG or W	N61SNG or W	N61PBG or W	N61SBG or W	N61PGG or W	N61PSG or W
13A SWITCHED FUSE CONNECTION UNIT WITH FLEX OUTLET	N62BNB	N62PCG or W	N62BSG or W	N62SNG or W	N62PBG or W	N62SBG or W	N62PGG or W	N62PSG or W
13A SWITCHED FUSE CONNECTION UNIT WITH NEON AND FLEX OUTLET	N63BNB	N63PCG or W	N63BSG or W	N63SNG or W	N63PBG or W	N63SBG or W	N63PGG or W	N63PSG or W
13A SWITCHED FUSE CONNECTION UNIT	N64BNB	N64PCG or W	N64BSG or W	N64SNG or W	N64PBG or W	N64SBG or W	N64PGG or W	N64PSG or W
13A SWITCHED FUSE CONNECTION UNIT WITH NEON	N65BNB	N65PCG or W	N65BSG or W	N65SNG or W	N65PBG or W	N65SBG or W	N65PGG or W	N65PSG or W
13A UNSWITCHED FUSE CONNECTION UNIT WITH FLEX OUTLET	N66BNB	N66PCG or W	N66BSG or W	N66SNG or W	N66PBG or W	N66SBG or W	N66PGG or W	N66PSG or W
13A UNSWITCHED FUSE CONNECTION UNIT WITH NEON AND FLEX OUTLET	N67BNB	N67PCG or W	N67BSG or W	N67SNG or W	N67PBG or W	N67SBG or W	N67PGG or W	N67PSG or W

Contemporary Design

Ultra Slim Metallic Front Plate



Contemporary Design List

PRODUCT NUMBER EXPLANATION:

N ☐☐☐

- SHROUD COLOUR
- PLATING COLOUR CODE
- PRODUCT CODE
- CONTEMPORARY DESIGN RANGE

CATEGORY OF THE PLATING COLOUR:

COLOUR	PLATING COLOUR CODE
BLACK NICKEL	BN
POLISHED CHROME	PC
BRUSHED STEEL	BS
STAIN NICKEL	SN
POLISHED BRASS	PB
SATIN BRASS	SB
PURE GOLD	PG
PURE SILVER	PS

SHROUD COLOUR

COLOUR	SHROUD COLOUR CODE
WHITE	W
GREY	G
BLACK	B

*Remarks:'B'(BLACK) is only used for the plating colour of 'BN'(BLACK NICKEL) products.

EXAMPLE:

PRODUCT NO	PRODUCT CODE	PLATING COLOUR CODE	SHROUD COLOUR CODE
N01PCW	N01	PC	W
N01SBG	N01	SB	G
N01BNB	N01	BN	B

Contemporary Design

Ultra Slim Metallic Front Plate

FYM®

Web site: http://www.fungyip.com